

Installing the New O-Rings

TOOLS NEEDED: 11 mm Wrench and Socket, Crescent wrench, small flathead screwdriver or a small pick



1. Turn off the water supply to the yard hydrant and relieve the water pressure by raising the handle.



2. Using the crescent wrench unthread and remove the square head set screw.



3. Using the 11 mm wrench and socket, loosen the fulcrum nut/bolt and slide the bolt out.



4. Remove the yard hydrant handle and linkage.



5. Rotate the brass connector and slide over the top of the clevis rod.



6. Using the crescent wrench, unscrew the packing nut, and slide it over the top of the clevis rod



7. Using a small flat screwdriver or pick, remove the packing O-rings from the hydrant head casting.



8. Find the new O-rings in the repair kit from the package marked with your color yard hydrant. Slide the new O-rings over the top of the clevis rod and push gently into the yard hydrant head using the small flathead screwdriver.



9. Re-install the packing nut. **DO NOT OVERTIGHTEN**

10. Re-install the brass connector (see #5 picture)



11. Re-install the linkage and handle at the same time.



12. Re-install the fulcrum bolt/nut



13. Re-install the square head set screw and tighten with the hydrant handle in the up or "ON" position

14. Turn the water on and test for leaks. If the yard hydrant leaks at the packing nut, tighten the packing nut until there is no water leaking.